How to nmi a Tezro Deskside

Published 03/29/2006

Symptom(s):

How to nmi a Tezro Deskside

Fact(s):

SGI Tezro Workstation
L1

SGI Solution:

There are 2 ways to NMI this system
1) Connect to the serial or usb L1 port on the back of the system.
and enter the 'nmi' command at the L1 prompt.

2) Open the door on the front the the system. Then using a flat tip screwdriver, remove
the front panel surrounding the L1 Display. On the exposed L1 display are a set of
buttons the right most one is labeled "NMI".

Answers others found helpful

- Silicon Graphics Tezro
- How-to interpret the Tezro LED information
- SGI® Man Page Library

Additional Details

Creation Date	09/11/2005 02:05 AM
Last modification	01/15/2016 04:29 PM
Published Date	03/29/2006
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • How To/Question